




# Extension Cable


## TS-05D/ TS-10D/ TS-20D/ TS-30D/ TS-50D/TS-100D/ TS-02DM/ TS-02D/TS-02M/TS-003DR/TS-003DRM




TS-05D (6-Pin Conference Cable) 5M Male-Female Extension Cable




TS-10D (6-Pin Conference Cable) 10M Male-Female Extension Cable




TS-20D (6-Pin Conference Cable) 20M Male-Female Extension Cable




TS-30D (6-Pin Conference Cable) 30M Male-Female Extension Cable




TS-50D (6-Pin Conference Cable) 50M Male-Female Extension Cable




TS-100D (6-Pin Conference Cable) 100M Male-Female Extension Cable




TS-02D (6-Pin Conference Cable) 2M Male-Male Extension Cable




TS-02DM (6-Pin Conference Cable) 2M Male-Female Extension Cable




TS-003DR (6-Pin Conference Cable) 0.3M Female-RJ45 Female Extension Cable



TS-02M (6-Pin Conference Cable) 2M Female-Female Extension Cord



6-pin aviation interface extension cable dimension figure



This interface is close to the host

This interface is close to the unit

TS-003DRM (6-Pin Conference Cable) 0.3M Female-RJ45 Female Extension Cable

